



Hisense Sero 8 Front and Back Camera Set Replacement

This guide demonstrates how to replace the front and back camera set in the Hisense Sero 8.

Written By: Katherine



INTRODUCTION

After extended use, the camera on your device may lose its proper function. Your front/back camera may be defective. Use this guide to replace the front and back camera set.

Step 1 — Front and Back Camera Set



- Remove the back cover of the device using a combination of both plastic opening tools.
- Use your plastic opening tool pry open a corner of the device, then continue down the side of the device with the tool to completely open the device.

Step 2



- Pull the latch up towards you to unlock the ribbon cable using your fingers.

Step 3



- Using the pointed end of the spudger, remove the front and back camera by lifting the camera out of the mother board.
- Carefully pull out the camera set with the tweezers.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-18 09:42:38 PM.